



**Unico 1100 Drive  
HELP Diagnostics  
Dec. 2016**

3725 Nicholson Road  
Franksville, WI 53126-0505

(262) 886-5678

Copyright © 2016 by Unico, Incorporated.

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Unico, Inc.

Printed in the United States of America.

The information contained within this manual is considered accurate to the best knowledge of the supplier at the time of publication. The manufacturer, however, assumes no liability for errors that may exist. The supplier reserves the right to change information and specifications without notice.

# 1. Help Display


The **Help Display** menu option is selected from the SETUP MENU of the drive. Use help to determine feedback, analog, view PIO, adjust the calendar, view clock settings, view process stack space, view the controller states and other options described below.

The help display contains utilities to help determine fault conditions, or aid in the startup and debugging process. The help display also contains utilities useful to help determine and maintain program optimization.

## 1.1 FEEDBACK

This utility accesses variables associated with the feedback transducers. Variables associated with each transducer type are summarized below. The type of transducer interface option installed on the drive will determine which set of variables are displayed. Pressing the down arrow key will scroll to the next variable. Holding the down arrow key while pressing the function key will scroll to the previous variable.

There are up to 2 sockets available of the S1000 module. Each socket on the DSP board is identified by a name as defined in the diagram below.



### 1.1.1 Incremental Encoder (Pulse Generator)

An incremental encoder or pulse generator provides differential inputs for quadrature channel configuration. Encoders should be wired following the hardware wiring manual for the drive. The help screen provides the following information to assist in verifying the feedback device. Pressing the down arrow key will scroll to the next variable. Holding the down arrow key while pressing the function key will scroll to the previous variable. The socket name precedes the display variable.

- **Motor PG Position**  
The accumulated incremental position of the encoder is displayed in units of pulses. Holding the function key while pressing the zero key resets the accumulated position to zero.
- **Motor PG Velocity**  
Encoder velocity is displayed in units of revolutions per minute.
- **Motor PG Mark Count**  
This counter is incremented on each transition of the encoder marker pulse. Once the count reaches 99, it will roll over to 0. Holding the function key while pressing the zero key resets the counter to zero.
- **Motor PG Mark Distance**  
The number of encoder pulses accumulated between the two most recent marker pulse transitions is displayed. This value will be positive, negative, or zero depending upon the direction of rotation and changes in the direction of rotation. Non-zero values should be equal to either plus or minus four times the encoder size.
- **Motor PG Mark Fault**  
Deviation from the expected marker distance for the two most recent marker pulse transitions is displayed in units of pulses.
- **Motor PG Ref Count**  
This counter is incremented on each transition of the reference input on the encoder interface. Once the count reaches 99, it will roll over to 0. Holding the function key while pressing the zero key resets the counter to zero.
- **Motor PG Ref Distance**  
This counter is the number of pulses between the reference pulse.

### **1.1.2 Xless( Transducerless)**

Transducerless connections refer to a motor that has no feedback device connected to it. Transducerless operation uses an internal velocity estimator to regulate the motor speed, so a transducer is not needed. The help screen provides the following information to assist in verifying the xless feedback. Pressing the down arrow key will scroll to the next variable. Holding the down arrow key while pressing the function key will scroll to the previous variable. Transducerless display values are shown preceded by Xless.

- Xless( Transducerless )Velocity  
Xless velocity is displayed in units of revolutions per minute.

- Xless( Transducerless ) Position

The accumulated incremental position is displayed in units of pulses. Holding the function key while pressing the zero key resets the accumulated position to zero.

### 1.1.3 Resolver

The resolver feedback device is an absolute encoder. The feedback from the device will produce an absolute position of 0 to 65535 for each revolution of the encoder. Some resolvers have multiple turns that require the resolver to turn multiple times before the absolute position limit is reached. The help screen provides the following information to assist in verifying the xless feedback. Pressing the down arrow key will scroll to the next variable. Holding the down arrow key while pressing the function key will scroll to the previous variable. The socket name precedes the display variable.

- Load Res Position

The accumulated incremental position of the resolver is displayed in units of pulses. Holding the function key while pressing the zero key resets the accumulated position to zero.

- Load Res Velocity

Resolver velocity is displayed in units of revolutions per minute.

- Load Res Raw Pos

Resolver absolute position is displayed in units of pulses from the zero position. The value will roll over to 0 after each complete revolution.

## 1.2 ANALOG

The ANALOG utility allows monitoring of the real-time value of the various analog input channels. The first line is a center-zero bar graph that displays  $\pm 100\%$  of full scale. The second line contains the description and present value of the analog input signal. The value is scaled such that a value of  $\pm 10$  corresponds to  $\pm 100\%$  of full scale. Pressing the down arrow key will scroll to the next analog signal. Holding the function key while pressing the down arrow key will scroll to the previous analog signal.

Available analog input signals are summarized below.

### 1. U voltage

This is a real-time display of the U phase motor voltage level. The maximum value of 10 is equal to 100% of peak armature voltage.

2. V voltage

This is a real-time display of the V phase voltage level. The maximum value of 10 is equal to 100% of peak armature voltage.

3. U current

This is a real-time display of the U phase motor current level. The maximum value of 10 is equal to 100% of peak armature current.

4. V current

This is a real-time display of the V phase motor current level. The maximum value of 10 is equal to 100% of peak armature current.

5. analog In 3

This is a real-time display of analog channel 3. The maximum value of 10 is equal to 100% of the full-scale input.

6. bus voltage

This is a real-time display of the bus voltage level. The maximum value of 10 is equal to the bus over voltage trip level.

7. analog in 1

This is a real-time display of analog channel 1. The maximum value of 10 is equal to 100% of the full-scale input.

8. analog in 2

This is a real-time display of analog channel 2. The maximum value of 10 is equal to 100% of the full-scale input.


### 1.3 PIO

The PIO option will display the status of the parallel inputs and outputs. Inputs and outputs should be assigned using the dictionary reference of the input or output data item. Refer to the documentation on these dictionaries to setup the inputs or outputs.

The io status can be viewed from the HELP / PIO screen. The output status can also be viewed in the output dictionary at the end of the list of bits. Readouts are prefixed with a “!”.

Once on the help PIO screen, IO bits can be viewed 16 at a time. The bit can be selected by typing in the bit number, or using the arrow key to scroll through the words. Information shows the state of the bit .

Use FUNCTION 0 to scroll through the function assigned to a specific bit. More than one input function can be assigned to a single bit.



#### 1.3.1 PIO Word Definitions

Each IO word defined in the application can have functions associated with the word. Functions are assigned to a specific bit in the word using the input and output configuration dictionaries. Refer to the INPUT dictionary documentation and the OUTPUT dictionary documentation for information on how to assign input request functions to word bits, and output bits to output status functions. The IO words that are displayed in the PIO help view are defined below:

- HDW – Configurable Bits either inputs or outputs depending on the setting of the word bit selection from the IO data items. Inputs are outputs are configured from the IN SETUP dictionary, or the OUT SETUP dictionary or from the GLOBAL dictionary by selecting the function that will be used by the bit. Outputs that are configured on a certain bit override inputs, so outputs and inputs cannot be configured on the same bit. Inputs have the 'req' suffix applied to the name, and outputs have the 'sts' suffix applied to the name.
- SIN – Serial inputs. These are available when a serial protocol that has been configured to use the IO bits is configured such as RIO. The **serial IO source** must be setup to the appropriate protocol before the IO can be assigned.
- SOUT – Serial outputs. These are available when a serial protocol that has been configured to use the IO bits is configured such as RIO. The **serial IO source** must be setup to the appropriate protocol before the IO can be assigned.
- PLCOUT-LOUT-LHOUT-LRELAY-INT – UEdit designated IO mapping words. These bits are used by UEdit applications, and must be viewed by using the UEdit program.

## 1.4 CLOCK

The CLOCK option will display the status of the internal clocks. Each foreground clock runs at a specified frequency that is a multiple of the clock frequency setup. There are 5 clocks configured, each has a multiple setup associated with it in the dictionary. Refer to change the clock multiple.

### 1.4.1 Settings

The clock settings view displays the current running frequency of each clock. Clocks are configured in either the global dictionary, or from the setup dictionary by modifying the multiple of the clock.

**clock frequency** - The frequency of the slowest control loops in the drive. Clock frequencies are determined at power-up, so if this item is changed, control power to the drive must be cycled. This setup is modified from the dictionary.

**drive multiple** - Drive multiple sets the frequency of all the routines which execute on the drive clock. The drive controller is the main routine which runs on the drive clock. If the **clock frequency** is at 50 Hz and the **drive multiple** is a 5, the drive clock runs at  $50 * 5 = 250$  Hz. Clock frequencies are determined at power-up, so if this item is changed, control power to the drive must be reset. This setup is modified from the dictionary.

**upid multiple** - The position/velocity loop controller runs on the upid clock by this multiple. If the drive clock is at 250 Hz and the upid multiple is a 4, the upid clock runs at  $250 * 4 = 1000$  Hz. Clock frequencies are determined at power-up, so if the multiple item is changed, control power to the drive must be reset. This setup is modified from the dictionary.

**ac multiple** - The ac vector controller runs on the ac clock. This clock runs faster than the upid clock by this multiple. If the upid clock is at 500 Hz and this multiple is a 2, the ac clock runs at  $500 * 2 = 1000$  Hz. Clock frequencies are determined at power-up, so if the multiple item is changed, control power to the drive must be reset. This setup is modified from the dictionary.

**ac fast multiple** - The ac vector rotator runs on the ac fast clock. This clock runs faster than the ac clock by this multiple. If the ac clock is at 1000 Hz and this multiple is a 2, the ac clock runs at  $1000 * 2 = 2000$  Hz. Clock frequencies are determined at power-up, so if the multiple item is changed, control power to the drive must be reset. This setup is modified from the dictionary.

### 1.4.2 Foreground Ticks & Overruns

The overrun view shows the number of ticks for each AC Clock, and also any overruns that may have happened on one or more of the other clocks.

The screen displays the overrun count in each clock, Fast Clock(FOr), Ac Clock(AOr), Upid Clock(UOr), Drive Clock(DOr), and Slow Clock(SOr). Each item has an accumulator for the number of overruns on the clock level. Select F0 to reset the overrun counts.



### 1.4.3 Clock Synchronization

Select the RTC(real time clock) from the clock menu to display the settings of the RealTimeClock that is used to synchronize control loops. The RTC display screen shows the connection state either INT for internal, or WAIT for waiting to connect to a master, or SYNC when synchronized to a master RTC clock. The clock source is either Internal or External when it is configured as a slave using the RTC mode setup in the dictionary.

The STC display shows if the clock is synchronized to the gate array switching frequency.

### 1.4.4 Timing

Select the Timing option from the clock menu to display the percent usage for each foreground clock. The clock is displayed followed by the percent of the clock that is used. Over 100% would produce an overrun. Increasing the usage on a clock will increase the usage on all the clocks slower than that one. Clock usage may change with time depending on what code is executed during the time slice. The usage percent displays the highest value, and can be reset by using Fn 0.

- fast – Percent of clock used
- ac – Percent of clock used
- upid – Percent of clock used
- drv – Percent of clock used
- slo – Percent of clock used

### 1.4.5 Clock Tasks

Select Task List from the clock menu screen to scroll through the list of tasks posted on the specified clocks.

## 1.5 PROCESS

The PROCESS display shows the amount of memory consumed by an individual background process. The arrow down key and function arrow keys can be used to scroll up and down through the processes configured within a device.

Once a process has been selected, Use the Fn1 key to display the Scan time in msec of the process, and the Maximum scan time in msec. Scan time is the amount of time from one background scan to the next.

Press Fn1 again to display the Exec time to executable time for the process. The executable time is the amount of time the specific process took during its execution.

Press Fn1 again to display the process state.

Press Fn1 again to display the starting address of the process in memory.

## 1.6 CALENDAR

The CALENDAR chip maintains the current time and date of the device. This chip stores the calendar set time and date, and updates this continually even when power to the drive has been lost.

To change the calendar date or time, select the calendar display from the help menu options, and then press the enter key to edit the date. Continue to press the ENT key until the cursor is at the item that is desired to be changed, then press the down arrow key until the desired item displays the correct value.

Access level 3 must be granted before the time or date can be altered.

## 1.7 CONTROLLER

The CONTROLLER help option displays data about the controller. The state of the controller is displayed first, and indicates the current status of the controller. The controller is used to manage the drive on and off states, and charging unit states if they are used. Other information in the controller help screen displays the status of the bits associated with the controller.

The controller help screen is used by Unico personnel to service drives, and make repairs.

## 1.8 SSI

The SSI ( Synchronous Serial Interface ) is a high speed serial protocol written by Unico. This protocol transfers a minimal amount of data at very high speeds and is typically used to couple drives together by electronically synchronizing them. If the SSI is not used, the screen will show “ssi disabled”.

If the ssi is configured to only transmit data, the number of data packets transmitting will be displayed, and can be reset by pressing function and zero keys together.

If the ssi is configured to receive data or transmit and receive data, the screen will display the takeovers, faults, communication errors, packets received, and the current state.

- **tkov** - indicates the number of times the hardware has detected a loss of the rtc synchronous signal.
- **flt** - indicates the number of faults. A fault is a bad or no packet of data. The fault count is any receive error, receive overrun error, or general receive errors.

- **cerr** - indicates the number of consecutive errors.
- **pcks** - indicates the number of received packets.
- **state** - indicates the current state of the SSI link. The state can be one of the following states:
  - INT - Internal
  - SOUR - SOURCE**
  - WAIT - Wait
  - MEAS - Measure
  - SYNC - Synchronized
  - PLL Phase Lock Loop

To clear faults or reset the data use the function zero keys.

## 1.9 MEM

The MEM display is used by Unico personnel only. This display helps the Unico development team track down and destroy annoying memory leaks or memory allocation problems.

## 1.10 Dictionary

The GLOBAL Dictionary displays all defined data items. User defined items are displayed here as well. The dictionary must have level 3 access to edit values. This dictionary cannot be removed or modified by UEdit™. This dictionary should be used as a reference source to the data items created within.

## 1.11 Network Map

The network map contains a parameter connection to data items. This is useful when upgrading software, and a PLC or other device has to talk to the software, but will not be modified to the new data layout. The network map provides a connection between the old data item indexes, and the new data item indexes.

Each network map must be constructed by the user, and can be done using any text editor, and downloaded using the archive menu. Alternatively, UEdit provides a network map modifier that uses standard drag and drop techniques and a simple download function to create the map.

When creating the network map in an archive file, the end of the file should contain the network map indicated by NETWORK\_START, after the data from the archive, indicated by DATA\_END. If no data archive is used, the DATA\_END can be omitted. The network starting offset or reference made by the network device ( PLC or other communicating device) should be set to some value, and each item will be incremented from the start of the network offset. In the example below, the offset is 1000, and the 4 items would be at 1000, 1001, 1002 and 1003.

```

DATA_END
NETWORK_START
NETWORK_OFFSET      1000 [dd]
vel preset 1   [ac]  $network item 1000
vel preset 2   [$$]
vel preset 3   [$$]
vel preset 4   [$$]
NETWORK_END

$END

```

**Figure 1** An example of the archive file text that can be used to create a network map. When the archive is uploaded from the drive, any network map will be displayed in the format shown above at the end of the archive file.

### 1.12 NVMEM

The NVMEM display is used by Unico personnel only. This display helps the Unico development team track down and destroy annoying memory leaks or memory allocation problems.

### 1.13 PORTS

The S2000 drives have 3 onboard configurable serial ports.

- The **download** port located on the left center of the motherboard configured as a RJ8(phone) connector.
- The **console** port located on the top of the mother board next to the keypad connector.
- The **fiber** port located on the top of the mother board next to the power connector.

Other ports are available as **port A** and **port B**, by adding an additional communication card.

The PORTS display shows what serial port has been configured for use. The port must have a protocol running before it will show up in the help. Select the port in question, each port displays first:

- RCNT Character receive count incremented each time a character is received.
- QIN Count is incremented to the maximum qin buffer size, and then reset. QIN and QOUT should match.
- QOUT Count is incremented each time a character is removed from the input buffer.
- CHAR the last character read.
- SIZE the input buffer size.

Select the arrow down key to display the Transmit port information.

- TCNT Character transmit count incremented each time a character is sent.
- QIN Count is incremented to the maximum buffer size, and then reset.

- QOUT Count is incremented to the maximum buffer size, and then reset. QIN and QOUT should match as this indicates that the buffer is functioning properly, and not missing characters.
- CHAR is the last character written out.
- SIZE is the output buffer size.

Select the arrow down key again to display protocol specific help screens.

## 1.14 UEDIT

The UEDIT help option displays information about any UEdit™ application that may be installed in the device. If UEdit™ is not available to this device, the UEDIT menu option will not display.

### 1.14.1 Execution Times

The display screen shows the following status about UEdit™ applications.

- **En** - Enable indicates that the UEdit™ application has been enabled and is running if it is set to a 1. If the value is set to a zero, the UEdit™ application is not running and must be started with UEdit™. Refer to UEdit™ documentation on how to enable a UEdit™ application.
- **Scan** - This value represents the current scan time taken to execute UEdit™ tasks posted on the process level clock and any other tasks posted on the process clock level by the application. This value is in milliseconds. This value can be reduced by reducing the foreground overhead by lowering scheduled clock levels.
- **Max** - The maximum process clock time. This value will grow during downloads, but indicates the longest run time ever. Large values are not uncommon because during downloading much data is written to NVRAM which takes a long time. To reset this value select the function and zero keys together.
- **Exe** - The longest execution time for the entire list of UEdit™ tasks on the process clock level. This value differs from the Scan time value in that it only accounts for the time used by the UEdit™ tasks, and not any other process tasks posted by the application. This value is in milliseconds.

### 1.14.2 Modification Date/Time

Pressing the down arrow key from the UEdit™ help menu option, will display the UEdit™ revision time and date. This indicates when the UEdit™ application was last modified.

### **1.14.3 Program Name**

Depress the arrow key again from the modification date and time screen, and the UEdit™ program name is displayed to indicate the program number or name that has been loaded and is executing in the drive.

### **1.14.4 NVRAM**

The next item in the UEDIT display screen can be reached by selecting the down arrow key. This screen displays the amount of available non-volatile ram in the device, under the NVSz label, and the amount of non-volatile ram available under the NVAv label. Non-volatile ram is used to store UEdit™ applications until they are written to program flash using the archive store utility. The NVRAM partitions may be modified using UEdit™.

### **1.14.5 Status**

The next item in the UEDIT display screen can be reached by selecting the down arrow key. This screen displays any UEdit™ errors that may have occurred when the UEdit™ application powered up.

## **1.15 System Errs**

The system error log is used to record programmatic errors since power on.

## **1.16 Other Help Options**

Help menu options are dependent on the configuration of the device and the optional communication and hardware cards installed on the device. Refer to the protocols documentation for additional information on help screens.

## UNICO – Worldwide

---



Corporate Headquarters

Unico, Inc.  
3725 Nicholson Rd.  
P. O. Box 0505  
Franksville, WI  
53126-0505

262.886.5678 main  
262.504.7396 fax  
[www.unicous.com](http://www.unicous.com)



Unico is a leading global innovator of motion-control solutions for industry. Founded in 1967, the company develops, manufactures, and services variable-speed drives, application-engineered drive products, integrated drive systems, and ancillary products that improve operations by increasing productivity, safety, and equipment life while lowering energy and maintenance costs.